

GBT-212 Glass Break Simulator


The GBT-212 is designed for the testing of acoustic glass break detectors. It detects the air pressure changes caused by the flexing or bending of glass and then automatically generates sound imitating the breaking of the glass. It is also possible to trigger the sound manually using the test button.

Specification

| | |
|-------------------------|--|
| Power supply | 9 V battery (type 1604) |
| Power consumption | 6 mA in stand by Max. 200 mA 30 uA after automatic turn off (the switch remains in the ON position) |
| Operating range | 9 m |
| Low battery warning | from 8 V |
| Environmental class II. | General interior (-10 to +40 °C) |
| Complies with | EN 50130-4, EN 55022 |
| Dimensions | 70 x 135 x 29 mm |

Complies with the essential requirements of: 89/336/EC EMC Directive - Protection concerning electromagnetic compatibility when is used for its intended purpose. Original of the conformity assessment can be found at the web page www.jablotron.cz, section Technical support.

Note: Dispose of batteries safely depending on the type of the batteries and local regulation. Although this product does not contain any harmful materials we suggest you to return the product to the dealer or directly to the producer after usage.



Operation

- Switch on the GBT-212 tester using the ON-OFF slide switch.
- The LED will flash rapidly for 4 sec during the warm up period
- When the LED is permanently lit, the tester is ready for use.
- Place the tester close to the window you want to test. The speaker of the simulator must face towards the glass break detector.
- Hit the glass with a suitable object or with a safety glove. The air pressure change will activate the GBT-212 and the breaking glass sound will be generated.
- Confirm the correct reaction of the glass break detector and, if it is necessary, adjust its sensitivity according to its manual.
- Next test is possible after apr. 4 sec, indicated by the LED being continuously lit.
- The glass break sound can also be activated by pressing the test button.

Attention! Do not place the tester close to your ears! Keep away from children!

Manual mode

You can switch the tester to its manual mode. Switch on the GBT-212 tester keeping the test button pressed. The air pressure detector will be by-passed and the simulator can be triggered only by pressing the test button. This mode is indicated by a flashing LED.

Battery replacements

Use only quality alkaline 9V batteries for this simulator. When the power voltage drops below 8 V, the LED indication will switch off. To conserve battery life, the tester switches off automatically when there is no testing for more than 10 minutes. You can switch the GBT-212 on again using the switch.



Pod Skalkou 33
466 01 Jablonec nad Nisou
Czech Republic
Tel.: +420 483 559 999
fax: +420 483 559 993
Internet: www.jablotron.cz

GBT-212 Glass Break Simulator


The GBT-212 is designed for the testing of acoustic glass break detectors. It detects the air pressure changes caused by the flexing or bending of glass and then automatically generates sound imitating the breaking of the glass. It is also possible to trigger the sound manually using the test button.

Specification

| | |
|-------------------------|--|
| Power supply | 9 V battery (type 1604) |
| Power consumption | 6 mA in stand by Max. 200 mA 30 uA after automatic turn off (the switch remains in the ON position) |
| Operating range | 9 m |
| Low battery warning | from 8 V |
| Environmental class II. | General interior (-10 to +40 °C) |
| Complies with | EN 50130-4, EN 55022 |
| Dimensions | 70 x 135 x 29 mm |

Complies with the essential requirements of: 89/336/EC EMC Directive - Protection concerning electromagnetic compatibility when is used for its intended purpose. Original of the conformity assessment can be found at the web page www.jablotron.cz, section Technical support.

Note: Dispose of batteries safely depending on the type of the batteries and local regulation. Although this product does not contain any harmful materials we suggest you to return the product to the dealer or directly to the producer after usage.



Operation

- Switch on the GBT-212 tester using the ON-OFF slide switch.
- The LED will flash rapidly for 4 sec during the warm up period
- When the LED is permanently lit, the tester is ready for use.
- Place the tester close to the window you want to test. The speaker of the simulator must face towards the glass break detector.
- Hit the glass with a suitable object or with a safety glove. The air pressure change will activate the GBT-212 and the breaking glass sound will be generated.
- Confirm the correct reaction of the glass break detector and, if it is necessary, adjust its sensitivity according to its manual.
- Next test is possible after apr. 4 sec, indicated by the LED being continuously lit.
- The glass break sound can also be activated by pressing the test button.

Attention! Do not place the tester close to your ears! Keep away from children!

Manual mode

You can switch the tester to its manual mode. Switch on the GBT-212 tester keeping the test button pressed. The air pressure detector will be by-passed and the simulator can be triggered only by pressing the test button. This mode is indicated by a flashing LED.

Battery replacements

Use only quality alkaline 9V batteries for this simulator. When the power voltage drops below 8 V, the LED indication will switch off. To conserve battery life, the tester switches off automatically when there is no testing for more than 10 minutes. You can switch the GBT-212 on again using the switch.



Pod Skalkou 33
466 01 Jablonec nad Nisou
Czech Republic
Tel.: +420 483 559 999
fax: +420 483 559 993
Internet: www.jablotron.cz